

cr8D receiver instructions.txt

English

Receiver and Transmitter Setup Instructions

By following these steps you will ensure your transmitter and receiver are properly setup and ready to fly.

1. Turn the transmitter on and adjust your transmitter to PPM mode and then turn the transmitter off.

2. Press and hold the programming button on the transmitting module, then turn the transmitter on. Please make sure the antenna has been attached to the transmitter module before turning on the transmitter. The LED on Module will flash between red and yellow indicating the transmitter is ready to program.

3. On the back of the receiver is a button Press and hold the button on the receiver. Connect the receiver to the battery. Plug the battery in so the positive lead is toward the top or lettering. The number side of the receiver is the positive side. The LED on the receiver will flash two times, then it flashes for about 5 seconds, indicating the receiver and transmitter are communicating on the same frequency. Turn off the transmitter and receiver.

4. Turn the transmitter on, the light on the transmitter module will turn red. Connect the receiver to the battery. The LED on the receiver will light red without any flash indicating the receiver is operating properly. If the LED on the receiver flashes turn both units off and power both up again until the receiver light goes solid red.

After following these steps to program your transmitter and receiver both modules will continue to operate on the same frequency each time you use the modules. If there is a need to reprogram your modules (adding another receiver) repeat steps 1 to 4. We hope you enjoy your new 2.4 Ghz receiver and transmitter modules. They have been designed and produced using the highest quality control measures available. If you have any questions please do not hesitate to contact us or visit our website.

Type:

[CR8D](#)

Size:

46.6x26x14.9mm(1.83"x1"x0.58")

Weight:

13.1g

Range:

>1.5km/4900ft

Sensitivity:

-100dbm

Number of Channel:

8

Operating voltage:

4.8V-6V

Operating current:

30mA

Transfer rate:

128kpbs

Resolution:

10bit

Compatible with:

CT8F/CT8J /CT8Z/CT3F/CT14F(DSSS)

Latency:

22ms



DEUTSCH

Empfänger und Sender-Setup-Anleitung

Durch die folgenden Schritte stellen Sie sicher dass ihr Sender und Empfänger korrekt eingerichtet und bereit zum Betrieb ist.

1. Schalten Sie den Sender ein und stellen Sie Ihren Sender auf PPM-Modus und schalten Sie dann den Sender aus.

2. Halten Sie die Programmiertaste am Sendemodul, dann schalten Sie den Sender ein. Bitte stellen Sie sicher, dass die Antenne auf das Sender-Modul angebracht worden ist vor dem Einschalten des Senders.

Die LED auf dem Modul wechselt zwischen rot und grün(gelb) blinkend damit ist der Sender bereit zum Programmieren (Binden).

3. Betätigen Sie auf der Rückseite des Empfänger die Taste, und drücken (halten) Sie die Taste am Empfänger.

Schließen Sie den Empfänger an die Batterie. Stecken Sie den Akku mit der positive Leitung in Richtung des oben liegenden Schriftzug. Die LED auf dem Empfänger wird zweimal blinken, dann blinkt sie etwa 5 Sekunden lang und zeigt an das der Empfänger und Sender auf der gleichen Frequenz kommunizieren.

Schalten Sie den Sender und Empfänger aus.

4. Schalten Sie den Sender ein, es wird das Licht auf dem Sender-Modul rot. Schließen Sie die Empfänger an der Batterie. Die LED am Empfänger leuchtet rot, ohne Blitzen.

Das ist die Angabe dass der Empfänger ordnungsgemäß funktioniert. Wenn die auf dem Empfänger-LED blinkt schalten Sie die Einheiten aus und wieder ein, sowohl am Sender als an dem Empfänger leuchten die LED konstant rot.

Nach diesen Schritten zur programmieren Ihren Sender und Empfänger werden beide Module weiterhin auf der gleichen Frequenz arbeiten bei jeder Verwendung der Module. Wenn es notwendig ist, (Hinzufügen eines weiteren Receivers) wiederholen Sie die Schritte 1 bis 4 neu zum programmieren (binden).

Wir wünschen Ihnen viel Freude mit Ihrem neuen 2,4 Ghz Empfänger und Sender-Module. Sie wurden entwickelt und produziert mit den höchsten Qualitätskontrollen zur Verfügung. Wenn Sie irgendwelche Fragen zögern Sie bitte nicht uns zu kontaktieren oder besuchen Sie unsere Homepage.



Type: CR8D

Masse: 46.6x26x14.9mm(1.83"x1"x0.58")

Gewicht: 13.1g

Reichweite: >1.5km/4900ft

Empfindlichkeit: -100dbm

Kanäle: 8

Spannung: 4.8V-6V

Stromaufnahme: 30mA

Transfer Rate: 128kpbs

Resolution: 10bit

Kompatibel mit: CT8F/CT8J /CT8Z/CT3F/CT14F(DSSS)

Latenz zeit: 22ms