


Four-channel Electronic Switch Manual



Function:

Four output channel output from first to fourth cycle, for example: line connection AUX channel, stroke ratio to +100%, the first channel output voltage, Close the other channels. stroke ratio to -100%, the first channel closed. When the second open to + 100%, the second channel output voltage, close the other channels. So on. The first to fourth output channel cycle. Each channel is corresponding to the output of the LED indicator. The input line every time to reconnect, application or return to the first channel control.

