

- “Beep—Beep—” : Both protection are ON

Mode Setting

To check current status :

- Switch on ESC and check Motor's “Beep—”
 - Motor “Beep—” or “Beep—Beep—” + “SI—LA—SO—” or “SO—LA—SI—” + LED Blink
Status : Practice Mode
 - Motor “Beep—” or “Beep—Beep—” + “SI—LA—SO—” or “SI—LA—SO—” + LED ON
Status : Climbing Mode

To Program :

- Switch on ESC,
- Hold “Programming Switch” for 2 Second to change Mode, release to program according to Motor's “Beep—”
 - Default Status : Practice Mode
 - “Beep—” : Practice Mode.
 - “Beep—Beep—” : Climbing Mode