







# 船 爆炸图

## RC Boat Instruction manual

| No. | 名称 规格      | Name                        | Pcs |
|-----|------------|-----------------------------|-----|
| 1   | 船体         | boat body                   | 1   |
| 2   | 船电子保护盖     | electronic protective cover | 1   |
| 3   | 舵机固定板      | servo fixed plate           | 1   |
| 4   | 座椅支撑架      | seat support rod            | 2   |
| 5   | 固定保护盖螺丝    | screws of protective cover  | 2   |
| 6   | 座椅         | seat                        | 2   |
| 7   | 防护罩-前      | protective cover-front      | 1   |
| 8   | 防护罩-后      | protective cover-back       | 1   |
| 9   | 防护罩连接件     | protective cover connecter  | 3   |
| 10  | 风叶总承       | blade assembly              | 1   |
| 11  | 马达上座-右     | upper motor mount-right     | 1   |
| 12  | 马达上座-左     | upper motor mount-left      | 1   |
| 13  | 碳钎马达支架     | CF motor support rod        | 2   |
| 14  | 马达下座       | upper motor mount           | 2   |
| 15  | 马达座        | motor mount                 | 1   |
| 16  | 舵下座        | servo bottom mount          | 1   |
| 17  | 舵叶定位座-下    | rudder blade fixed-bottom   | 2   |
| 18  | 舵叶-右       | rudder blade-right          | 1   |
| 19  | 舵叶-左       | rudder blade-left           | 1   |
| 20  | 舵叶定位-上     | rudder blade fixed-upper    | 2   |
| 21  | 舵叶平位连杆     | rudder blade linkage rod    | 2   |
| 22  | 球头         | ball link                   | 5   |
| 23  | 舵叶连杆球头     | rudder blade ball link      | 1   |
| 24  | 螺丝TM 2×6mm | screws TM 2×6mm             | 6   |

|    |            |                   |    |
|----|------------|-------------------|----|
| 25 | 无头螺丝3×3mm  | screws 3×3mm      | 6  |
| 26 | 螺丝KM 2×7mm | screws KM 2×7mm   | 5  |
| 27 | 无头螺丝3×4mm  | screws 3×4mm      | 2  |
| 28 | 螺丝TM 2×5mm | screws TM 2×5mm   | 12 |
| 29 | 螺丝HM 2×7mm | screws HM 2×7mm   | 4  |
| 30 | 舵机连杆       | servo linkage rod | 1  |
| 31 | 防水电子线口胶    | waterproof robber | 1  |
| 32 | 防水舵机拉杆口胶   | waterproof robber | 1  |